



PLANET FRIENDLY®

Chlorinating Your Well

- 1)** Stick a hose from the outside tap down the well and start the water re-circulating.
- 2)** Add the chlorine very slowly about $\frac{1}{4}$ gallon at a time.
- 3)** Turn the faucet off, bypass the water treatment systems, and bring the chlorine smell to every faucet in the house hot and cold.
- 4)** Let the chlorine sit in the lines for 24 hours.
- 5)** Turn on all faucets until the chlorine smell goes away.

Note - It will take 1 gallon of high strength chlorine per 100 feet of well per 100 feet of well.